




Multi-head Adjustable Accent modules with a clean closed face. Use them alone or mix and match with our DLTB Series Down Lights or our DWTB or MPTB Series Wall Washers.




# INSTALLATION INSTRUCTIONS

## AAMTB SERIES T-Bar Mounting

FOR SUPPLY CONNECTIONS ENTERING THIS FIXTURE, USE WIRE SUITABLE FOR AT LEAST 90° C

### \* INSTALLATION TO BE DONE IN ACCORDANCE WITH NEC AND APPLICABLE CODES \*

- 1.** For most installations, secure the fixture to the T-Bar (typical as shown, or per local regulations).






- 2.** Mount fixture to sit on top of T-Bar. To correct height, adjust the mounting brackets with the screws inside fixture housing.




- 3.** Connect power through the cover plate or knock-outs.

**A)** To access the transformer/ballast, after installation, push the spring clip at the edge of fixture to allow the face to drop down.


**B)** With the face down, you may remove (2) nuts at the top of the fixture to remove the Wiring Cover Plate.




- 5. MR-16 LAMPS:** With fixture face open, the MR-16 lamp plugs into the socket and is secured into lamp shroud with a spring clip at the back as shown.



- 5. PAR LAMPS:** With the face open, the PAR lamp screws into the socket and is secured into lamp shroud with a lamp securing disk at the back as shown.



- 6.** After installation and lamping, replace the Wiring Cover Plate and secure with nuts.



- 7.** Snap the face of the fixture back in place, over the spring clips.

